



**STAGE 1**

Excavate planting holes to minimum 1000x1000x300 mm deep below finished levels.

**STAGE 2**

Break up sub-base to 100 mm.

**STAGE 3**

Backfill with 50/50 mixture of site soil/mushroom compost mixed with 130 gr. of fertiliser.

**STAGE 4**

Place tree/shrub into hole.

**STAGE 5**

Install two 1500x30x30mm stakes to each tree taking care to avoid root ball.

**STAGE 6**

Fix two 50 mm wide webbing ties to each tree.

**STAGE 7**

Leave 600x600mm opening in grass and finish soil level 50mm below the surrounding grass.



SCALE 1: N.T.S.

SUBDIVISION  
CODE

CITY OF SHOALHAVEN  
TREE PLANTING  
GUIDE

ENGINEERING WORKS  
MANAGER

DRAWN C. FIESELER

CHECKED J. BLOM

PLAN REF. 263729

DATE 05. MAY 1994