

Safe Work Instruction - Star Picket Driver

DO NOT use this plant* unless you have been inducted in its safe use and operation by an Authorised Experienced Operator

This SWI may not cover all possible hazards and risks and should be referred to as a control measure in the risk assessment process.

Additional training may be required for high risk plant. Site and task may change required PPE.

PERSONAL PROTECTIVE EQUIPMENT



Eye protection must be worn



Hand protection must be worn



High visibility clothing must worn



Foot protection must be worn

POTENTIAL HAZARDS AND RISKS

(i) Crushing

Crushing due to being trapped between plant and fixed structure

Manual Task Injury

Manual task injury from repetitive movements Manual task injury from plant vibration

(î) Other

Injury from contact with moving parts
Injury due to operating of plant in unsuitable weather
conditions

PRE-OPERATIONAL SAFETY CHECKS

- Complete site specific risk assessment
- Complete visual plant check before operation
- Ensure you are familiar with plant operations and controls
- Check ground conditions, ensure the ground is firm.
- ✓ If it is suspected that utility lines are in the works area, ensure you have the correct "Dial Before You Dig" plans available BEFORE you start work
- ✓ Ensure the handles are free from grease and oil

OPERATING PROCEDURES

- Keep clear of moving plant parts
- ✓ Stand the post in the required position by lightly tapping the post into the ground with a hammer
- ✓ Place the star picket driver onto the post. Ensure the post is in a vertical position and the star picket driver is on a parallel plane to the post
- Ensure the operator maintains a stable standing position with feet as far apart as the width of the shoulders. Keep body weight balanced
- Stand firmly and always hold plant with both hands
- ✓ Let the tool do the job, use a firm, but minimum hand grip, consistent with proper control and safe operation
- If the plant seems to have hit a concealed object, stop ramming immediately. Ensure there is no danger before continuing

ENDING OPERATIONS

 Ensure plant is in good working order and stored in the appropriate location Electrical Shock or Burn

Electrocution/shock from plant coming in contact with concealed electrical services

Slip, Trips, Falls

Slip, trip, fall due to uneven or slippery work surfaces Slip, trip, fall due to steep working surfaces

DO NOT

- Do not use if plant is faulty. Attach a DO NOT OPERATE tag and report fault to your supervisor
- Do not place hands on top of star picket when inserting it into the picket driver
- Do not operate plant unless both feet are in contact with the ground
- Do not wear loose jewellery
- Do not use mobile phone while operating plant

*Plant in this SWI refers to any machinery, equipment, appliance, container, implement and tool.

 TRIM Ref: 53289E
 Adopted: 15.04.2016
 Last Amended:
 Review Date: 15.04.2019
 Version: 1
 Page 1 of 1