

Safe Work Instruction - Ceiling Spaces - Access & Working In

DO NOT use this plant* or complete this task unless you have been inducted in its safe use and operation by an Authorised Experienced Operator

This SWI may not cover all possible hazards and risks and should be referred to as a control measure in the risk assessment process.

Additional training may be required for high risk plant/work. Site and task may change required PPE.

PERSONAL PROTECTIVE EQUIPMENT



Eye protection must be worn



Foot protection must be worn



Hearing protection must be worn



Minimum P2 face mask or respirator must be worn when airborne dust or fumes are created



Protective body clothing must be worn



Hand protection must be worn



Head protection must be worn



High visibility clothing must worn

POTENTIAL HAZARDS AND RISKS

(i) Cutting, Stabbing or Puncturing
Injury from work piece disintergrating

Manual Task Injury

Manual task injury from awkward body posture Manual task injury from incorrect manual handling techniques

(i) Electrical Shock or Burn

Electrical shock or burn from damaged or poorly maintained electrical leads and cables

Electrical shock or burn from water near electrical equipment

Electrical shock or burn from plant contact with live electrical conductors

(i) Exposure to Dust/Fumes

Exposure to Dust
Exposure to Asbestos
Exposure to Toxic Fumes

Slip, Trips, Falls

Slip, trip, fall due to uneven or slippery work surfaces

Struck by Moving Object

Struck by moving object due to work pieces being ejected

① Other

Injury due to fall from heights
Exposure to contaminated air
Exposure to asbestos
Irritation from excessive dust
Exposure to hazardous chemicals

PRE-OPERATIONAL SAFETY CHECKS

- ✓ Complete site specific risk assessment
- Complete the appropriate pre-operational plant checklist
- Ensure you are familiar with plant operations and controls
- Ensure that all electrical equipment to be used has been tested and tagged for construction sites
- Implement control measures including but not limited to, adequate lighting, ventilation and testing of ceiling strength
- ✓ If the area has been determined to be treated as a confined space then follow the Confined Space Procedure

OPERATING PROCEDURES

- ✓ Keep clear of moving plant parts
- Operate plant to the conditions of the work area
- Ensure no person or animal is endangered when operating plant

- ✓ Set up access to roof area using appropriately identified method e.g. scaffolding, ladder
- Ensure identified isolations, tags and locks are complete and fitted
- ✓ Ensure you are aware of the location of electrical cables or electrical equipment
- Check power leads are in good working order and do not create a trip hazard
- ✓ If required, install planks along access route in ceiling and use planks to form a working platform area at work site. Ensure planks are fitted across ceiling joists and that the span and size of the joists have been considered during completing the risk assessment
- Ensure your entry and exit point is able to be accessed with ease
- Workers to have sufficient temporary lighting
- ✓ If in any doubt of the capacity of the ceiling joists to support your weight, consult with the Shoalhaven City Council Building Maintenance Supervisor

TRIM Ref: SWI6[v2] | Adopted: 15.04.2016 | Last Amended: 01.08.2019 | Review Date: 01.08.2022 | Version: 2 | Page 1 of 2



✓ Carry out programmed works and maintain contact with second person outside ceiling space, normally this is possible through ceiling or via manhole access. If deemed necessary from the risk assessment, set up routine welfare checks via direct voice contact, phone or two way radio

ENDING OPERATIONS

- Replace any insulation material that may have been disturbed or moved for access to the work area, ensuring that it is not covering any electrical fittings or equipment
- Clean worksite, remove all tools and materials and
- Test and then remove isolations and confirm the site is left in a safe and functional way
- Wash your hands, face, neck and hair with soap and water

EMERGENCY RESPONSE PROCEDURE

- ✓ If you lose contact with the worker you must verify they are safe immediately. If you determine there may be a threat to their health and safety you may at any point call for assistance from Emergency Services 000
- ✓ Confirm electrical isolations and re-check atmospheric conditions in the ceiling if safe to do so
- Continue to attempt contact with worker. If safe to do so, plan a course of action with them, apply first aid if needed. If assistance is required to extricate them from the ceiling space, assist them via the crawl boards or planks that lead to the worksite. Do not enter the ceiling or attempt to assist the person unless it is safe to do so
- ✓ If an injured person cannot be extricated easily by the entry route, gain access to them by cutting or removing sections of the ceiling or roofing material. Set up scaffold or ladder under person to assist them to climb down from the ceiling if you and the injured worker agree this can be done safely
- If injured worker is unconscious, or cannot be moved, continue first aid and wait for rescue services

DO NOT

- Do not use plant if faulty. Attach an Out of Service tag and report fault to your supervisor
- Do not leave plant running unattended
- Do not use electrical equipment in wet conditions
- Do not use equipment capable of generating noxious gas in the work area
- Do not wear loose jewellery
- Do not use mobile phone while operating plant

*Plant in this SWI refers to any machinery, equipment, appliance, container, implement and tool.